# Wiring Diagram & **Schematic SAFETY WARNINGS**

### Safety Alert Symbols

The safety alert symbol (A) is used to identify hazards that can result in personal injury. A signal word (DANGER, WARNING or CAUTION) is used with the alert symbol to indicate the potential severity of injury. In addition, a hazard symbol may be used to represent the type of hazard.



**DANGER:** Indicates a hazard which, if not avoided will result in death or serious injury.



WARNING: Indicated a hazard which, if not avoided could result in death or serious injury.



**CAUTION:** Indicates a hazard which, if not avoided might result in death or serious injury.

**CAUTION**: When used without the alert symbol, indicates a situation that could result in damage to equipment or components.

# HAZARD SYMBOLS AND MEANINGS Explosion Shock **Disconnect** Spark Plug **Entanglement**





Generators produce powerful voltages. Failure to isolate generator from power utility can result in death or injury to electric utility workers due to backfeed of electrical energy.

 When testing generators used for backup power, notify utility company.

**CAUTION**: The measuring equipment used in troubleshooting this equipment should be of industrial quality and should have the sensitivity to measure electronic values to the third decimal. Its accuracy should conform with acceptable industry tolerances. Ensure that all specified tools and/or equipment are available before attempting to troubleshoot.


### **DANGER**



Physical contact with energized electrical components will result in dangerous and possibly fatal electrical shock.

 Do not touch bare wires or receptacles.

### **CAUTION**



 Only qualified electrical technicians should attempt to service this equipment.

### **▲** WARNING




Accidental starting of the unit may cause entanglement or electrocution.

- Where applicable, disconnect the negative (-) battery terminal.
- Disconnect the spark plug wire.
- Remove the control panel fuse when available. WD-SCH-07

Rev: 081805


# **SCHEMATIC**



### SCHEMATIC

Copyright © 2006 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

## WIRING DIAGRAM



WIRE DIAGRAM

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com