

Carrier

A GUIDE TO OPERATING AND MAINTAINING YOUR RESIDENTIAL AIR CONDITIONER.

AIR CONDITIONER

Models 50NE and 50EE Single-Packaged Air Conditioners





NOTE TO INSTALLER:
This manual should be left with equipment user

WELCOME TO EFFICIENT COOLING COMFORT

Congratulations on your excellent choice and sound investment in home cooling comfort!

Your new air conditioner represents both the latest in engineering development and the culmination of many years of experience from one of the most reputable manufacturers of comfort systems.

Your new unit is among the most energy-efficient and reliable air conditioning products available today. To assure its dependability, spend just a few minutes with this booklet now. Learn about the operation of your air conditioner and the small amount of maintenance it takes to keep it operating at its peak efficiency.

With minimal care, your air conditioner will provide you and your family with satisfying home comfort—both now and for years to come.

IMPORTANT FACTS

To better protect your investment and to eliminate unnecessary service calls, familiarize yourself with the following facts:

A WARNING

Improper installation, adjustment, alteration, service, maintenance or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency, distributor or branch. The qualified installer or agency must use only factory authorized kits or accessories when modifying this product.

- Your air conditioning system should never be operated without a clean air filter properly installed. Plan to inspect the filter periodically. A clogged air filter will increase operating costs and shorten the life of the unit.
- Supply-air and return-air registers should not be blocked. Drapes, furniture, and toys are some of the items commonly found obstructing grilles. Restricted airflow lessens the unit's efficiency and life span.
- Outdoor units must have unrestricted airflow. Do not cover the unit, lean anything against it, or stand upon it. Do not allow grass clippings, leaves, or other debris to accumulate around or on top of the unit. Maintain a 12-in. minimum clearance between the outdoor unit and tall grass, vines, shrubs, et cetera.
- Your multipurpose indoor thermostat is the control center for your air conditioning system. You should familiarize yourself with its proper operation. Attempting to control the system by other means—for instance, switching the electrical supply power ON and OFF—may cause damage to the unit.
- Thermostat "jiggling" causes rapid-cycling, which is potentially damaging to the compressor. Do not move the temperature selector on the thermostat for any reason for at least 5 minutes after the compressor has shut off.
- You may find that you can maintain greater personal comfort by running the fan continuously. "Air pockets" can form due to the structure of the building, placement of registers, et cetera. These air pockets may be too cool or warm for your liking. Continuous fan operation minimizes any temperature differences. Also, systems equipped with elec-

tronic air cleaners and/or humidifiers offer the added benefits of having the air continuously cleaned year-round, and humidified during the winter season.

• Your air conditioner will remove humidity from your home during the cooling season. After a few minutes of operation, you should be able to see water trickle from the condensate drain of the cooling coil. Check this occasionally to be sure the drain system is not clogged. Of course, don't expect to see much drainage if you live in a very dry environment.

OPERATING YOUR AIR CONDITIONER

The operation of your air conditioning system is controlled by the indoor thermostat. You simply adjust the thermostat and it maintains the indoor temperature at the level you select. Most thermostats for air conditioning systems have three controls. These are the temperature control selector, FAN switch, and SYSTEM switch.

The temperature control selector is a dial or lever that allows you to establish the degree of temperature that you wish to maintain for your personal comfort. Some thermostats possess two temperature control selectors: one for setting the temperature desired during the cooling cycle, and one to set the heating operation temperature (if the accessory electric heater is used). Typical settings are 78 degrees Fahrenheit for cooling and 68 degrees for heating.

The FAN switch offers two options for controlling the blower: AUTO and ON. When set to AUTO, the blower will run during the time the air conditioner is operating. When the FAN switch is set at the ON position, the blower will run continuously.

Typically, the SYSTEM switch on your thermostat offers the following selections: COOL, OFF, and HEAT. Your thermostat may also have a fourth selection, AUTO. The air conditioner will not operate when the SYSTEM switch is set at the OFF position. With the SYSTEM switch set at COOL, the cooling section of your comfort system will operate when the indoor temperature rises above the level that you wish to maintain. With the SYSTEM switch set at the HEAT position, the accessory electric heater will operate automatically whenever the indoor temperature falls below the level that you have selected.

The AUTO selection found on some thermostats provides for automatic changeover between cooling and heating cycles. With the SYSTEM switch set in the AUTO position, the cooling mode is activated when the indoor temperature rises above the thermostat cooling temperature setting, or the heating mode will be activated when the indoor temperature drops below the thermostat setting for the heating cycle.

COOLING CYCLE

When operating in the cooling cycle, your air conditioner will run until the indoor temperature is lowered to the level you have selected. On extremely hot days, your air conditioner will run for longer periods at a time and have shorter "off" periods than on moderate days.

The following are typical conditions that add extra heat and/or humidity to your home. Your air conditioner will work longer to keep your home comfortable under these conditions:


- Entrance doors are frequently opened and closed
- Laundry appliances are being operated
- A shower is running
- More than the usual number of people are present in the home

- More than the normal number of electric lights are in
 use
- Drapes are open on the sunny side of the home

HEATING CYCLE

If you own a packaged air conditioner that includes electric heat as an accessory, you need only program your thermostat for heating.


With the SYSTEM switch of your indoor thermostat set to the HEAT position, the heating section of your home comfort system will operate until room temperature is raised to the level you have selected. Of course, the heating unit will have to operate for longer periods to maintain a comfortable environment on colder days and nights than on moderate ones.



PERFORMING ROUTINE MAINTENANCE

With the proper maintenance and care, your air conditioner will operate economically and dependably. Maintenance can be accomplished easily by referring to the following directions. However, before performing maintenance, consider these important safety precautions:

- DISCONNECT ALL ELECTRICAL POWER TO THE AIR CONDITIONER BEFORE REMOVING ACCESS PANELS TO PERFORM SERVICE OR MAINTENANCE. For a packaged air conditioner unit, disconnect power to the unit and any supplemental electric heaters. NOTE: THERE MAY BE MORE THAN ONE ELECTRICAL DISCONNECT SWITCH.
- ALTHOUGH SPECIAL CARE HAS BEEN TAKEN TO MINIMIZE SHARP EDGES IN THE CONSTRUCTION OF YOUR UNIT, BE EXTREMELY CAREFUL WHEN HANDLING PARTS OR REACHING INTO THE UNIT.



CHECK THE AIR FILTER

A dirty air filter will cause excessive strain on the compressor and blower motor. This can cause the components to overheat and automatically shutdown. In the extreme, the

components will fail and need to be replaced. To avoid inefficient or failed operation of your unit, CHECK THE FILTER(S) EVERY 3 TO 4 WEEKS. Replace filter(s) when necessary, or clean the filter(s) if you have the reusable type.

Disposable filters should be replaced by similar, new filters of the same dimensions.

Reusable, permanent filters should be washed in a solution of cold water and mild detergent, then rinsed and thoroughly dried. THE FILTER MUST BE COMPLETELY DRY BEFORE BEING REINSTALLED. To avoid prolonged shut down of your unit while a filter is drying, you should have an extra filter on hand. This would allow you to rotate between the two with minimal downtime for your comfort system. Extra filters may be purchased from your dealer.

The filter(s) and filter rack for a packaged system are supplied and installed by the contractor or dealer. Typically, the filter(s) and rack are located in the return-air duct at the outdoor unit or behind the return-air grille(s). Have your dealer show you the location of your filter(s) and the procedures for removal and replacement.

If you have any questions about the removal and/or cleaning of your filter(s), contact your dealer for assistance.

If grass clippings, leaves, shrubbery, and debris are kept away from the unit, minimal care should be sufficient to keep the system functioning properly. However, if the outdoor coil becomes dirty, use a brush or vacuum cleaner and soft brush attachment to clean the exterior surface. If dirt is deep in the coil, contact your dealer for service. The outdoor fan motor may have to be disconnected and the top panel removed to gain access to the coil for thorough cleaning. Do not attempt this yourself.

UNIT SUPPORT

Your packaged unit should be maintained at a level position. If its support should shift or settle so that the unit is no longer level, you should correct the condition. Relevel it promptly to assure condensate drainage out of the unit. If you notice that water or ice collects beneath the unit, arrange for it to be drained away from the unit.

BEFORE YOU REQUEST A "SERVICE CALL" BEFORE YOU CALL FOR SERVICE, CHECK FOR THESE EASILY SOLVED PROBLEMS:

Check the indoor and outdoor disconnect switches. Verify that circuit breakers are ON or that fuses have not blown.

Check for sufficient airflow. Check the air filter(s) for any accumulations of dirt. Check for blocked return-air or supply-air grilles. Be sure grilles are open and unobstructed.

Check the settings on your indoor thermostat. If you desire cooling, see that the temperature control selector is set below room temperature and the SYSTEM switch is on the COOL or AUTO position. If you require warmth, be sure the temperature control selector is set above room temperature and the SYSTEM switch is at HEAT or AUTO. The FAN switch should be set at ON for continuous blower operation or AUTO if you wish the blower to function only while the unit is operating.

If your comfort system still fails to operate, contact your servicing dealer for troubleshooting and repairs. Specify your apparent problem, and state the model and serial numbers of your equipment. (You should have them recorded on page 4 of this booklet.) With this information, your dealer may be able to offer helpful suggestions over the phone, or save valuable time through knowledgeable preparation for the service call.

REGULAR DEALER MAINTENANCE

In addition to the routine maintenance that you perform, your home comfort system should be inspected regularly by a properly trained service technician. The inspection (preferably each year, but at least every other year) should include the following:

- Routine inspection of air filter(s). Replacement or cleaning as required.
- Inspection and cleaning of the blower wheel, housing, and motor. Service should include proper lubrication of these components.
- Inspection and, if required, cleaning of indoor and outdoor coils.
- Inspection of the indoor coil drain pan, plus the primary and secondary drain lines. If supplied, the auxiliary drain pan and line should be inspected at this time. Service should include cleaning if required.
- A check of all electrical wiring and connections.
- A check for secure physical connections of individual components within units.
- Operational check of the air conditioner system to determine actual working condition. Necessary repair and/or adjustment should be performed at this time.

FOR THE RECORD

Heater, if applicable:

Kilowatt Rating

Part No.

Record the model, product and serial numbers of your new equipment in the spaces provided below. This information, along with the other ready-reference facts requested below, will be necessary should you ever require information or service.

Inst	allation Data
Date Installed	
Dealer Name	
Address	
City	
State	Zip
	Unit Data
Product No.	
Model No	
Corial No.	





ETACH AND MAIL PRODUCT REGISTRATION

												ə	Her	plo	H					
detach and mail immediately for CT REGISTRATION	ES THAT YOU BE NOTIFIED OF ANY RECALLS INVOLV. E MODEL AND SERIAL NUMBERS OF YOUR PRODUCT ISE.	968		State Zip	and form an annual at a not	set, or from nameplace on SERIAL NO.	8. Which of the following have you done in the past 6 months? (check all that apply)	2. Ordered an item from mail order catalog 3. Sent in product inquiry card from magazine		9. In which age group are you?	1. 🗀 18-24 2. 🗀 25-34	3. 🗆 35-44 4. 🗀 45-54		10. Marital status: 1. Married 2. Unmarried 2. Unmarried 3.		11. Which group best describes your family moone? 1. □ Under \$10,000 6. □ \$30,000.\$34,999 2. □ \$10,000.\$14,999 3. □ \$15,000.\$14,999 4. □ \$20,000.\$24,999 9. □ \$45,000.\$44,999 5. □ \$25,000.\$29,999 10. □ \$50,000 & over	12. Do you nave any ciniques in any or use concerning ago groups who are living at home? 1. — Under age 2 2. — Age 2-4 3. — Age 5-7 4. — Age 8-10 4. — Age 8-10	 13. For your primary residence, do you: 1. □ Own a house? 2. □ Rent a house? 3. □ Own a townhouse/condominum? 4. □ Rent an apartment? 	Which of the following types of credit cards do you use? □ Travel/Entertainment (American Express, Diners Club, Carte Blanche) □ Bank (Master Charge, Visa) □ Gas, department store, etc.	15. What is your occupation? (check one) 1. □ Professional/Technical 7. □ Housewife 2. □ Upper Mgt./Administrator 8. □ Retired 3. □ Sales/Service/Middle Mgt. 4. □ Clarical/White Collar 5. □ Craftsman/Blue Collar 6. □ Student
IMPORTANT: Complete, detach	THE FEDERAL CONSUMER PRODUCT SAFETY ACT REQUIRES THAT YOU BE NOTIFIED OF ANY RECALLS INVOLY. ING THIS PRODUCT. YOUR NAME AND ADDRESS AND THE MODEL AND SERIAL NUMBERS OF YOUR PRODUCT WILL ASSIST US IN NOTIFYING YOU SHOULD THE MEED ARISE. WILL ASSIST US IN NOTIFYING YOU SHOULD THE MEED ARISE. Your warranty coverage is not dependent upon the return of this card.	1. 1. □ Mr. 2. □ Mrs. 3. □ Ms. 4. □ Miss tane (First/Inital/Last)	Street	3lty	_	MODEL NO. (Copy from computer card in packet, or from namephate on unit.)	NSTALLED / / / Mo. Day Yr.	 Synat Carrier product did you purchase? □ Central air conditioner 	%2. □ Gas furnace 3. □ Oil furnace 3.4. □ Flecting furnace	Heat pump	4. www.nen did you acquire your Carrier product? .0 1. Upon purchase of new dwelling			2-4 years after buying dwening with no central Over 4 years after buying dwelling with no central	ar system	5.6/f this was a replacement product, how old was the program of t		Office/Bank Store Hospital/School Manufacturing building Other	at 2 factors meet influenced your purchase? Carrier reputation Frend's recommendation Contractor/Dealer's recommendation Price Price Price Dealer's filterial	

 30. □ Gourmet Foods/Cooking 31. □ Health/Natural Foods 32. □ Wines 33. □ Fashion Clothing 34. □ Home Furnishings/Decorating 		37 Science Fiction 38 Astrology/Occult 39 Stock/Bond Investments	40. ☐ Real Estate Investments 41. ☐ Self Improvement Programs 42. ☐ Community/Civro Activities	We appreciate your taking the time to complete this card; the information provided will help us serve you better in the	tuture. We participate in a funit-company program more, you can receive information about new products, developments, trends, etc. related to the interest areas and other ments, trends, etc.	information you have indicated above. Please check here it you would prefer not to learn about such products and	services. Other comments & suggestions about our product:			
16. Which of the following interests and hobbies do you and your family enjoy? 1. □ Fanis 2. □ Golf	3. ☐ Snow Skiing 4. ☐ Runmig/Jogging	5. — Cartipus mining 6. — Horiting/Shooting 7. — Fishing	8. 🗆 Bicycling 9. n Racquetball 10. 🗆 Sailing/Boating		 14. □ Physical Fitness/Exercise 15. □ Home Video Recording 16. □ Decreational Vehicle(4WD) 		 19. Home Workshop/Do-It-Yourself 20.		29. ☐ Attending Cultural/Arts Events	

Fold Here

PLACE FIRST CLASS STAMP HERE

CARRIER AIR CONDITIONING Product Registration Center P.O. Box 17686 Denver, Colorado 80217

Carrier Air Conditioning

Division of Carrier Corporation



IF YOUR UNIT DOES NOT WORK, FOLLOW THESE STEPS IN ORDER:

FIRST: Contact the installer. You may find his name on the product or in your

Homeowner's Packet. If his name is not known, call your builder if yours

is a new residence.

SECOND: Contact the nearest CARRIER distributor (See telephone yellow pages.)

THIRD: Contact

Carrier Air Conditioning

Consumer Relations Department

P.O. Box 4808

Syracuse, New York 13221 Telephone. 1-800-CARRIER 1-800-227-7437

Unit Model No	Unit Serial No
Date of Installation	Installed by
Name of Owner	Address of Installation

Extended Protection Limited Warranty

ONE-YEAR WARRANTY—This CARRIER product is warranted to be free from defects in material and workmanship under normal use and maintenance for a period of one year from the date of original installation, whether or not actual use begins on that date. A new or remanufactured part to replace any defective part will be provided at Carrier's sole option without charge for the part itself, PRO-VIDED the defective part is returned to our distributor. This warranty applies only to the product in its original installation location and is voided if the product is reinstalled elsewhere.

THIS WARRANTY DOES NOT INCLUDE LABOR or other costs incurred for diagnosing, repairing, removing, installing, shipping, servicing or handling of either defective parts or replacement parts. SUCH COSTS MAY BE COVERED BY a separate warranty provided by the installer

EXTENDED FOUR-YEAR WARRANTY ON COMPRESSOR ONLY—During the second through fifth years after the date of original installation, CARRIER further warrants the compressor against defects in material or workmanship under normal use and maintenance A new or remanufactured compressor will be provided at Carrier's sole option under the same conditions as stated in the One-Year Warranty

LIMITATIONS OF WARRANTIES—ALL IMPLIED WARRANTIES (INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY) ARE HEREBY LIMITED IN DURATION TO THE PERIOD FOR WHICH EACH LIMITED WARRANTY IS GIVEN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THE EXPRESSED WARRANTIES MADE IN THIS WARRANTY ARE EXCLUSIVE AND MAY NOT BE ALTERED, ENLARGED, OR CHANGED BY ANY DISTRIBUTOR, DEALER, OR OTHER PERSON WHATSOFVER

ALL WORK UNDER THE TERMS OF THIS WARRANTY SHALL BE PERFORMED DURING NORMAL WORKING HOURS ALL

REPLACEMENT PARTS, WHETHER NEW OR REMANUFACTURED, ASSUME AS THEIR WARRANTY PERIOD ONLY THE REMAINING TIME PERIOD OF THIS WARRANTY.

CARRIER WILL NOT BE RESPONSIBLE FOR:

- 1 Normal maintenance as outlined in the installation and servicing instructions or owners manual including coil cleaning, filter cleaning and/or replacement and lubrication
- 2 Damage or repairs required as a consequence of faulty installation or application by others
- 3 Failure to start due to voltage conditions, blown fuses, open circuit breakers or other damages due to the inadequacy or interruption of electrical service
- 4 Damage or repairs needed as a consequence of any misapplication, abuse, improper servicing, unauthorized alteration or improper operation
- 5 Damage as a result of floods, winds, fires, lightning, accidents, corrosive atmosphere or other conditions beyond the control of CARRIER
- 6 Parts not supplied or designated by CARRIER
- 7 CARRIER products installed outside the continental USA, Alaska, Hawaii and Canada
- 8 Electricity or fuel costs or increases in electricity or fuel costs from any reason whatsoever including additional or unusual use of supplemental electric heat
- 9 ANY SPECIAL, INDIRECT OR CONSEQUENTIAL PROPERTY OR COMMER-CIAL DAMAGE OF ANY NATURE WHATSOEVER Some states do not allow the exclusion of incidental or consequential damages, so the above limitation may not apply to you

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Form No 530-001 (Rev 3/80)

Carrier

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or classified section of your local telephone directory under the "Heating Equipment" or "Air Conditioning Contractors & Systems" headings for dealer listing by brand name.

Have available the Model No., Series & Serial No. of your equipment to insure correct replacement part.

Carrier Corporation ● Syracuse, New York 13221

Manufacturer reserves the right to discontinue, or change at any time, specifications or designs without notice and without incurring obligations.

Form: OM50-16 Printed in U.S.A. 8-80 PC 101 Catalog No. 535-057

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com